



Thank you for making the investment with MFC Offroad as well as yourself. The MFC Offroad center console rocker panel will give your Cherokee an OEM look to and aftermarket solution. After careful measuring, CNC cad design, and proper procurement of an OEM finished satin black aluminum, you can now have up to 6 switches at your fingertips for all of your custom wired accessories.

When taking on this project, we advise you to watch the video in the below link to see how you can take the center console panel off with a couple pulls upwards. You can view this video here with the hyperlink:

[Jeep Cherokee Center Console Removal](#)

If you cannot click the link, please visit the Motor City Mechanic video link for Jeep Cherokee center console removal via YouTube.

Attached you will find all the necessary pictures for how to trim the factory console panel to allow you to use the MFC Offroad switch panel.

Thank you again for supporting us.

Tools needed to complete the lift:

1. Dremel with cut off wheel
2. Protective eyewear

Picture 1 (Shows what tools are recommended for installation)



Picture 2 (Shows what the panel looks like when removed)



Picture 3 (Shows what to trim off the bottom side for fitment of the rocker switches and relocation of the media center / 12 volt socket)



Picture 4 (Shows the recommended angle at which the panel will sit when placed into the factory location)

