Smart LabTools
Complex Forms made Simple

Evaluate QC Performance vs. Allowable Error Limits

< Enter Lab Name - Analyzer - Control Info. Here >

Reset Data
Reset Form
Z = 2.0

Analyte & TEa Reference	Ctrl	True Mean	Obsv Mean	Obsv SD	Obsv %CV	Bias Units	%Bias	Imprec Units	TE Units	%TEa Limit	TEa Units	TE/TEa Ratio	%TE	ME Units	ME SD	Delta SEcrit	Sigma Metric
TEST	L-1	100	105	2.5	2.50	5.00	5.00	5.00	10.00	10.00	10.00	1.00	10.00	0.00	0.00	0.35	2.00
TEST	L-2	200	210	2.5	1.25	10.00	5.00	5.00	15.00	10.00	20.00	0.75	7.50	5.00	2.00	2.35	4.00
TEST	L-3	300	315	2.5	0.83	15.00	5.00	5.00	20.00	10.00	30.00	0.67	6.67	10.00	4.00	4.35	6.00

***** INTERACTIVE EVALUATION TEMPLATE *****
Calculations are limited to the first three lines for each of 2-pages
Refer to References on Website for intended use

**** CLICK HERE TO DOWNLOAD PDF ****
Save to your computer (desktop)

- Requires Adobe Reader -

Mean(True) - as Published, Insert, Peer, Target
Mean(Obsv) - Observed Lab Mean from between day testing
SD(Obsv) - Lab Standard Deviation - between day testing
%CV(Obsv) - Calc. 100 * (SD / Mean(True))
Bias - Mean(True) - Mean(Obsv)
%Bias - 100 * ((Mean(Obsv) - Mean(True)) / Mean(True)
%TEa - Total Allowable Error (ATE), as with CLIA PT %CV
Imprecision - (SD(Obsv) * Zp), Zp is '2' for 2SD Limit

TE or TAE - Total Analytic Error = (Bias + Imprecision)
TEa or ATE - Total Error Allowed = (Mean(True) * CLIA PT %CV)
TE/TEa - <1.0 is Acceptable, .33 or Less Desired
%TE - %TE = %Bias + Zp * %CV
ME units - Margin for Error = (TEa - TE)
ME in SD - Margin for Error = (TEa - TE) / SD
Delta SEcrit - ((%TEa - %Bias) / CV%) - 1.65
Sigma Metric - (%TEa - %Bias) / CV%

Comments:

Reviewed by: 07/09/2017

DEMO TEMPLATE - UNLIMITED DISTRIBUTION ALLOWED
SLT_419 v.4.3, ©2015, SmartLabTools™ Daniel W. Leighton, HCLD(ABB), CLB

Smart LabTools
Complex Forms made Simple

Quality Control Performance Limits (SD's) vs. TEa

BV (TEa Limits)
Westgard (TEa)
CLIA PT Limits

< Enter Lab Name - Analyzer - Control Info. Here >

Analyte & TEa Reference	Ctrl	True Mean	Obsv Mean	Obsv SD	TEa Low	TEa High	2.0 SD Low	2.0 SD High	2.5 SD Low	2.5 SD High	3.0 SD Low	3.0 SD High	3.5 SD Low	3.5 SD High	4.0 SD Low	4.0 SD High	TEB %
TEST	L-1	100	105	2.5	90.00	110.00	100.00	110.00	98.75		97.50		96.25		95.00		100
TEST	L-2	200	210	2.5	180.00	220.00	205.00	215.00	203.75	216.25	202.50	217.50	201.25	218.75	200.00	220.00	75
TEST	L-3	300	315	2.5	270.00	330.00	310.00	320.00	308.75	321.25	307.50	322.50	306.25	323.75	305.00	325.00	67

Comments:

TEB(%) = Total Error Budget = (TE/Tea)*100,
TEB(%) should not exceed 50%; 33% or less is desired.

Reviewed by: 07/09/2017

DEMO TEMPLATE - UNLIMITED DISTRIBUTION ALLOWED
SLT_419 v.4.3, ©2015, SmartLabTools™ Daniel W. Leighton, HCLD(ABB),